


Installation Instructions

Replacement Of Elliptical Handle

| PROTECTIVE GEAR NOTICE | |
|---|--|
|  | <i>Protective Eyewear– Potential risk of eye injuries, protective eyewear required when performing this, and any other associated tasks.</i> |
|  | <i>Protective Gloves– Potential risk of injury to your hands, protective gloves required when performing this, and any other associated tasks.</i> |
|  | <i>Footwear Protective – Potential risk of injury to your feet, wearing protective footwear is required when performing this and any other associated tasks.</i> |

Safety and Warnings



BEFORE YOU BEGIN

Read instructions completely and carefully.

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK OR INJURY, OBSERVE THE FOLLOWING:

- 1) Use this unit in the manner intended by the manufacturer.
- 2) Before servicing or altering, switch power off.



For use inside a commercial refrigeration case with packaged foods only.

FOR YOUR SAFETY

Read and observe all CAUTIONS and WARNINGS shown throughout these instructions. While performing installations described; gloves, safety glasses or goggles should be worn.



PREPARE ELECTRICAL WIRING

Electrical requirements

This appliance must be supplied with 120V, 60 Hz, and connected to an individual and properly grounded branch circuit, protected by a 15 or 20 ampere circuit breaker or time delay fuse.

STEP 1 Clean the surface of the base of the handle with small towel to remove dirt and impurities. Apply the 3M adhesion promoter to the base of the handle, and set it for 30 seconds to cure. **Note:** Repeat both sides of the handle base.



STEP 2 Apply the elliptical handle tape by removing the white film liner. **Note:** Repeat both sides of the handle base.



STEP 3 Adhere it to the base of the handle. **Note:** Repeat both sides of the handle base.



STEP 4 Location of the handle of the door. Follow the adjacent door to acquire the measurements, and should be the center of the door.



STEP 5 Once the location to place the handle has been determined in STEP 4. Use small towel to clean the dirt and impurities from the glass surface. Apply the 3M adhesion promoter (Allow 30 seconds of drying time for curing) to the glass surface where the handle will be adhered to the glass using the VHB elliptical tape.



STEP 6 Apply pressure to the handle toward the glass surface and maintain the pressure for 30 seconds.

Revisions

| Rev. | Description | Date | Orig. | Inc. | Chk. |
|-------------|--------------------|-------------|--------------|-------------|-------------|
| A | Release | 2/1/2026 | HT | | |